



**Lotus
Transfer Press
Solutions**


Transferpressen und -material für den Textildruck

How to use our temperature stripes

Dear customer,

in order to receive exact results with our temperature strips, please follow these instructions:

- Set 160°C and 30 sec. on your heat press and wait 30 minutes
- Stick 5 strips in an diagonally mode on the lower printing plate and position them about 3 cm away from the plate edges.
- Close the heating plate and press for 30 sec.
- Discoloring of pads will show which temperature has been reached.
- Now you can see if the temperature you have set and the real temperature correspond. Or if in some area the real temperature is lower. In this case one or more heating elements could be damaged and needs to be replaced.
- After you finished the measurement, take a picture of the strips on the lower plate and stick them on a piece of paper. Give them a number from 1 to 5 starting with the strip which was on the lower left side of the plate.
- Send us the picture so that we can give you the right advice.
- You can use the same strips again to measure higher temperatures.



For example:

- 1st measurement 160°C – 30 sec.
- 2nd measurement 180°C – 30 sec.

If you have any further question, please contact us at any time.

Your Lotus Team

